

Quickguide

Touch R700 / Navi 900

Opel OnStar

The home screen contains applications including audio, telephone and navigation. Select them by pressing the icons on the touch screen.



Control elements below:

RADIO: Switch to radio. Press repeatedly to toggle between FM, AM or DAB.

MEDIA: Switch to media. Press repeatedly to toggle between CD, USB, Bluetooth®-Audio or AUX.

: Return to the home screen. Longpress (~2 seconds) to switch to Android™ Auto or Apple CarPlay™.

BACK: Return back to the parent menu.

 Turn to scroll lists. Press to select a list element.

Audio

 Switch to the main screen of the current audio source.



Change the audio source by pressing **RADIO** or **MEDIA**.

Open the list of radio stations or media files by pressing **BROWSE**.

Phone

 Switch to the main phone screen.



To pair a mobile device via Bluetooth, select **Pair Device** and follow the instructions. Make sure Bluetooth and all necessary settings are enabled on the mobile device.

After pairing, certain device settings may need to be enabled on the device itself (e.g. phone book).

Favourites

Favourites are at the bottom.



Radio stations, phone contacts, artists, playlists, navigation destinations, etc. can be stored as favourites.

Reveal favourites

If the favourites are hidden:

- Press the reveal button at the bottom of the screen or



- drag the interaction bar upwards.



Store favourites

Press and hold any favourite until a beep sounds to store an item.



If more than one screen item could be saved as a favourite (e.g. phone contacts), you will be

asked to select an item to store.



Navigation

Note: Not applicable to Touch R700.

On the navigation map screen, select **DESTINATION** to enter different types of destinations (e.g. an address or point of interest).

Voice recognition

Press Ⓜ on the steering wheel to start voice recognition. Wait for the signal to talk and refer to the help screen for valid commands.

Audio, phone and navigation

To call a contact e.g., say 'Call Anna Smith'. To play music e.g., say 'Play Artist Mozart'.

To start navigation, e.g. say 'Find address 123 High Street London'.

Smartphone voice recognition

Longpress Ⓜ on the steering wheel to activate the smartphone voice recognition (e.g. Siri®) while the phone is connected via Bluetooth or while using Android Auto or Apple CarPlay.

Android Auto and Apple CarPlay

With Android Auto and Apple CarPlay certified apps of compatible smartphones can be accessed

with the infotainment system. Check with your phone vendor, if your phone is compatible and if Android Auto or Apple CarPlay is available in the country you live in.

To use Android Auto and/or Apple CarPlay:

1. Download the Android Auto app to your phone from the Google Play™ store. There is no app required for Apple CarPlay.
2. Make sure Apple CarPlay or Android Auto is enabled in the infotainment system. Press **SETTINGS** on the home screen and then select Apple CarPlay or Android Auto.
3. Connect your Android Phone or Apple iPhone® with your USB cable to the USB data port. Use your device's factory-provided USB cable. Aftermarket or third-party cables may not work.

To use Android Auto, certain device settings may need to be enabled on the Android phone itself.



The **PROJECTION** icon on the home screen will change to Android Auto or Apple CarPlay. To launch Android Auto or Apple CarPlay select the icon on the home screen or longpress .

Press  to switch back to the home screen of the infotainment system.

Note: To charge a smartphone's

battery without starting phone projection, disable Apple CarPlay or Android Auto (step 2) and then connect the phone with a USB cable with the infotainment system.

Instrument display

The instrument display provides access to functions like audio, phone, navigation. Use the five-way controller on the right side of the steering wheel to operate.



-   Select menu items.
-  Enter a sub menu.
-  Return to the parent menu.
-  Confirm selection.

Note: Only applicable if your vehicle is equipped with Opel OnStar. 4G LTE Wi-Fi hotspot might not be available in certain countries.

OnStar is your personal connectivity and mobility assistant.

To sign up for OnStar, please contact your Opel dealership or press .

OnStar buttons

Three OnStar buttons are located in the overhead console (or interior mirror) in the vehicle.



- Access OnStar **Wi-Fi** settings menu.
- Accept incoming/end current OnStar advisor call.
- Activate location masking. Press and hold until you hear a voice prompt to enable/disable location masking. While enabled, the vehicle location is only transferred to OnStar in case of an emergency. Location masking setting will be kept until changed back.



- Connect to an OnStar advisor (e.g. for a remote diagnostics check, or to download a destination to your navigation unit).



- Place an emergency call that connects you with an OnStar advisor (e.g. in any case of an accident or medical emergency).

OnStar Wi-Fi hotspot

To connect a mobile device with the OnStar Wi-Fi vehicle hotspot:

1. Start a Wi-Fi network search on your mobile device.
2. Select your vehicle hotspot when listed.
3. Enter the password on your mobile device when prompted.

Press  to access the OnStar Wi-Fi settings to find out the vehicle hotspot name (SSID) and password.

For more information on OnStar and your infotainment system refer to the owner manual, press  or visit us online.

